Changing the SIM card in your CS10

Step	Action	Screen Display
1	Remove the cap from the top of your controller and remove the installed SIM. Replace it with the alternate SIM you wish to use. Secure the cap then turn on the controller. From the main menu select **3 Instrument** followed by **2 Connections**	
2	Select **3 All other connections**. Highlight **CS Internet** and select **Edit**.	

3	Change the **User ID** and **Password** to those relevant to the mobile network you wish to use. Those without entries should be left blank. (The table opposite is a guide only and some of the entries are untested. Please contact your network provider for details)	

Operator	User ID	Password	APN
Vodafone	web	web	internet
O2	faster	password	mobile.o2.co.uk
Orange			orangeinternet
Three			three.co.uk
GiffGaff	giffgaff	password	giffgaff.com
Tesco Mobile	tescowap	password	prepay.tesco-mobile.com
T-Mobile	user	wap	general.t-mobile.uk
Virgin Mobile	user		goto.virginmobile.uk
Asda Mobile	web	web	asdamobiles.co.uk
talk mobile	wap	wap	talkmobile.co.uk (contract)
			payg.talkmobile.co.uk(PAYG)

4	Having altered your user ID and password select OK and you will be returned to the connection settings screen. With **CS Internet** highlighted select **Cntrl..** at the base of the screen. Alter the **APN** to the relevant one from the table above then select OK.	
5	Return to the main menu and wait. Should the GPS not connect to the internet, turn the controller off and then on again to reboot the system with the new settings.	