

veito

CARBON INFRARED HEATER CH1200 LT

User's Manual



PRECAUTIONS

DESCRIPTION
OF USE

- Thank you for purchasing Veito Carbon Infrared Heater. Please read the instructions thoroughly before using your heater.
- After reading the instructions, please keep it in a place accessible to all users.
- Ensure you read 'Safety Precautions' in advance and use the product correctly.
- We can not be liable for any damages caused by failure to observe these instructions.
- The product is specified for use with a power supply of 230V 50/60Hz
- This manual includes the product warranty.
- Specifications and contents of this manual may be changed without prior notice, in accordance with our commitment to product quality, design and control.



CONTENTS

■ Safety Precautions.....	3
■ Precautions for installation and before use	7
•Precautions for install	7
•How to install	7
•How to use power.....	8
■ Configuration and name	8
•Main body	8
■ Indication and operation part	8
•Operation and stop	8
■ How to diagnose safety device	9
■ Cleaning and maintenance	9
■ Storage Instructions	9
■ Troubleshooting	10
■ Wiring diagram	10
■ Specification	10
■ Product warranty.....	11

Safety Precautions

These precautions are designed for keeping users safe and preventing material damage. Be sure to read them and use the product correctly.

- There are 3 classifications of safety precautions and they are listed in the box below.



Risk

Possibility of death or severe injury in the event of mishandling.



Warning

Possibility of death or severe injury in the event of mishandling.



Caution

Possibility of injury and/or material damage in the event of mishandling.

*Meaning of picture signs



Indicate prohibition



Indicate contents that people must carry out




Risk

*After reading this, be sure to keep it at a place where other users can refer to it at any time.






Do not leave or use pressure vessel around heater
(Can cause explosion)





WARNING

*After reading this, be sure to keep it at a place where other users can refer to it at any time.

<p>! Use specific 230V 16A amp socket. (to prevent fire & electric shock)</p>  <p>230V</p>	<p>! Ensure both plug and socket is clean and free from dust when using.</p> 	<p>⊘ Never use with a damaged power lead, plug or loose wall socket. (this can cause electric shock, short circuiting or fire)</p> 
<p>⊘ Never remove the plug from the socket by pulling the mains lead. Never touch the plug with wet hands. (risk of electrocution and/or fire)</p> 	<p>⊘ Do not extend the power cord. (risk of breakdown or fire)</p> 	<p>! Ensure you hold the power plug properly when either plugging in or unplugging.</p> 
<p>⊘ Do not kink or place the main power lead under heavy objects. (risk of electric shock or fire)</p> 	<p>⊘ Do not overload the dedicated power socket with other equipment.</p> 	<p>⊘ Always turn off the unit by use of its control knob and never by just pulling the mains plug or tripping the circuit breaker.</p> 
<p>! Ensure that the unit is properly earthed through the mains power circuit.</p> 	<p>⊘ Do not install, use or place any combustible liquids or gases near the product. (risk of fire or explosion)</p> 	<p>⊘ Never place the unit near combustible products such as curtains, carpets etc. This can cause a fire.</p> 
<p>⊘ Never put hands or objects into the main body of the product. Never touch it immediately after use. (risk of fire burns or electric shock)</p> 	<p>⊘ Never place combustible objects on the product such as vinyl and plastic items. (can cause a risk of fire)</p> 	<p>⊘ The heater must not be located immediately below a socket outlet when in use. (risk of fire)</p> 






veito



WARNING

*After reading this, be sure to keep it at a place where other users can refer to it at any time.

PRECAUTIONS

<p>Do not use this heater in the immediate surroundings of a bath, a shower, or a swimming pool. (electrocution and/or electric leakage can easily occur)</p> 	<p>Never move the product whilst it is switched on. Always turn it off and allow it to cool down before touching.</p> 	<p>Do not use the unit other than for its intended use. (do not use for drying clothing or for keeping animals or plants warm etc.)</p> 
<p>Never attempt to clean the unit with any solvents or flammable liquids. (this could cause electric shock or fire)</p> 	<p>Children being supervised not to play with the appliance.</p> 	<p>If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. (risk of electric shock or fire)</p> 
<p>Do not use the product whilst sleeping or away from the premises.</p> 	<p>Do not use this heater with a programmer, timer or any other device that switches the heater on automatically. Since a fire risk may exist if the heater is covered or positioned incorrectly.</p>	

veito



CAUTION


*After reading this, be sure to keep it at a place where other users can refer to it at any time.



The heater must be installed on a flat and even surface.



When thunder and lightning is present, turn off the unit and disconnect from the power supply. Disconnect from power supply when the unit is not being used for a long period.



Do not try to take the unit apart or repair it. Never jar the product.



Do not use the unit on unstable or unsafe surfaces.




Do not touch hot parts whilst in use. Do not place hands on the unit as it gets very hot during its heating operation. Always turn it off and allow it to cool before handling. Children must be kept away from the heater.



Do not clean the product before disconnecting from power and allowing it to cool down.



Keep heater away from other electric domestic appliances. (They could get damaged due to high heat)



Store the product in dry, indoor locations and not in hot or humid locations.



After storage, remove all dust before re-use.



Precautions for installation and before use


PRECAUTIONS FOR INSTALL

*After reading this, be sure to keep it at a place where other users can refer to it at any time.

<p>! Never install the heater on a combustible surface. (wood, carton etc.)</p> 	<p>! Install the product at places that are visible to people. (frequently observe the product for safety)</p> 
<p>! Install the product at places where users always reside and be sure to equip fire extinguisher.</p> 	<p>Do not install at places with high temperature.</p> 

HOW TO INSTALL

*Keep packaging parts because they are necessary in maintaining the heater for a long time.

<p>• Assemble the stand with the heater.</p> 	<p>• Secure the stand to the heater by using the connection screws supplied.</p> 
<p>• Always leave a clear space of at least 0.5m from the left and right of the unit. The unit must also have at least 1.8m clear space above it. Never put any obstacles nearer than 1.8m to the front of the unit.</p> 	<p>• Use the unit in places with easy access to power sockets and that are well ventilated.</p> <p>• Never use connecting terminals in the power lead. Always directly connect the unit to the power.</p> 


HOW TO USE POWER

- When using 230V
- Put plug into specific outlet for 230V with earth terminal.



Configuration and Name

MAIN BODY




•External appearance can be changed without prior notice for improving quality.

INDICATION AND OPERATION PART

OPERATION AND STOP

The appliance is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

1. Start operation by using Control Knob switch.
2. Heater is turned on and operation is started.
3. Use Control Knob switch to stop.



How to Diagnose Safety Device

SAFETY DEVICE

Veito heater is equipped with diverse safety device, preventing a risk of fire. In the event that heater is not working properly, safety device is operated and heater is automatically stopped.

When the heater is knocked over, it will automatically shut down.




Cleaning and Maintenance

Precautions for examination and handling;

- Handle heater when it is completely cooled down and power is cut off.
- If the heater has collected dust or dirt inside the unit or around the elements, have the unit cleaned by a qualified service agent. Do not operate the heater in this condition.
- Do not attempt to open the case of the heater at any time, there are no customer serviceable parts inside.
- Do not use powerful abrasive or solvent cleaning fluids when cleaning the heater as they may damage the plastic parts. Use only a clean, dry cloth to clean the external surfaces of the heater only.

Storage and Instructions

•Disconnect from power supply.



•Ensure main body is clean and dry.



•Cover the heater with the coveringsupplied when you purchased the unit. Keep it in a well ventilated dry place.




Troubleshooting

This heater was manufactured conscientiously and checked several times before delivery. If you experience a malfunction, please try to rectify the fault yourself first with the help of this table. In doing so, you will avoid the unnecessary expense of customer service assistance. If a fault in your heater can not be rectified with the aid of this table, please contact the Central Customer Service Department. Repairs must only be carried out by authorized professionals.

	Syptoms	How to deal with
Unit is not working	<ul style="list-style-type: none"> •Is electric supply working? •Check that the power plug is plugged in. •Is the circuit breaker off? 	<ul style="list-style-type: none"> •Check the main power supply is working. •Turn on the product once again after plugging in. •Reset circuit breaker.

Wiring Diagram



Specification

classification	model
Heating Capacity BTU/h	6000
Maximum Power (W)	1200
Space for use (m ²)	15
Power supply	AC 230V 50/60Hz
Size(mm) (WxLxH)	300x300x700
Product weight (kg)	2.0
Controlling method	Level Control
Controlling function	2 Levels

WARRANTY

(Applicable to first retail purchaser only)

Veito Carbon Infrared Heater give more reliable performance, comfort and durability the more they are used. They are built under a strict quality assurance regime which includes inspection both during and after production and exhaustive reliability testing.

In the unlikely event you have any problems, please contact your dealer or distributor. If the problem is as a result of a production fault or failure, repairs will be undertaken free of charge during the period of warranty subject to the following warranty conditions:

1. The warranty period is 12 months from the date of first purchase.
2. If the problem has been caused by customer error or misuse, abuse or damage, then all repairs will be charged for.
3. This warranty card is valid within your country.
4. Proof and date of purchase must be supplied.
5. Please complete the details below and keep this warranty in a safe place.
6. All transport charges back to the dealer are at the customers cost. Keep all original packaging to facilitate return. Return to customer will be at dealers cost (if genuine warranty claim).

DESCRIPTION	CARBON INFRARED HEATER	
MODEL	CH1200 LT	
DATE OF PURCHASE		PRODUCT SERIAL NO:
Warranty Period	() Months	
DISTRIBUTOR	Name of Company	
	Telephone No.	
CUSTOMER DETAILS	Name:	
	Address:	
	Telephone:	

veito

www.veito.com

veito